

The Aromatherapy System uses a small air pump and deck-mounted diffuser to distribute the scent of essential oil throughout the bathing area. This adds to the ambiance and relaxation of the bathing experience.

Aromatherapy Operating Instructions

1. Locate the aromatherapy diffuser unit on the deck of the walk-in tub.
2. Locate the sample packet of essential oils (Fig. 1).
3. Remove the cap from the tub's aromatherapy unit (Fig. 2).
4. Fill the aromatherapy unit with a few tablespoons of water.
5. Select the essential oil you will be using.
6. Using the built-in applicator, add 2 (two) to 4 (four) drops of essential oil into the water (Fig. 3).
7. If you are mixing several oils into a blend, treat the blend as a single oil (add no more than 4 [four] drops in total to the aromatherapy unit).
8. Once the oil is in the aromatherapy unit, you can activate the system at any time, regardless of whether you are bathing or not.
9. Press the "ON/OFF" button on the aromatherapy control pad to turn the system on. Press the "ON/OFF" button again to turn the system off.
10. A quiet bubbling can be heard when the system is active.

ON/OFF Button



Cleaning Instructions

1. You should clean the essential oil cup and diffuser every few weeks or prior to changing essential oils.
2. Remove the essential oil cup (Fig. 4) and add a few drops of rubbing alcohol to safely remove sticky oils from every part of the well. Wipe clean with a paper towel
3. Replace the essential oil cup, then run the aromatherapy system for 1 (one) to 3 (three) minutes.
4. Use a cotton swab to remove residual alcohol. Run the diffuser without any oils for a few minutes to ensure it dries thoroughly.

Fig. 1



Fig. 2



Diffuser

Fig. 3



Fig. 4



SAVE THESE INSTRUCTIONS